

DESCRIPTION

Nascom's N1178C 3750 Series is a 3/4" recessed stubby door contact designed for residential, commercial and industrial steel and wood door applications. The bare D3/8" X L1/2" cylinder NdFeB magnet provides extra installation flexibility.

The N1178C 3750 is the installer's choice of contact configuration because the contact set is designed to cut installation times and helps to prevent false alarms caused by shifting or warping doors.

The N1178C 3750 Series is designed for installation in every type of hinged door including wood doors.





FEATURES

- SNAP FIT ON STEEL - NO GLUE REQUIRED
- SCREW TERMINALS
- WIDE GAP - N35 NdFeB RARE EARTH MAGNET
- ENCAPSULATED HERMETICALLY SEALED CONTACTS
- POLYPROPYLENE HOUSINGS
- LISTED TO UL634 STANDARD


ORDERING INFORMATION

PART NUMBER	COLOR	OPERATE GAP (in inches)	CONTACT RATING (Max DC/Peak AC Resistive)				STATIC CONTACT RESISTANCE (50mV, 100mA)
			SWITCHING		CARRY		
			V	I	V	I	
CLOSED LOOP, NORMALLY OPEN, 1FA, SWITCH/MAGNET SET:							
N1178CT3750B/ST N1178CT3750G/ST N1178CT3750T/ST N1178CT3750W/ST	BROWN GREY TAN WHITE	0.875 to 1.50	200 VDC	0.5 Amps	10vA	1.5 Amps	150 mOhms
OPEN LOOP, NORMALLY CLOSED, 1FB, SWITCH/MAGNET SET:							
N1178CT3750B/STFB N1178CT3750G/STFB N1178CT3750T/STFB N1178CT3750W/STFB	BROWN GREY TAN WHITE	0.75 to 1.25	30 VDC	0.2 Amps	3vA	0.5 Amps	150 mOhms
HIGH SECURITY, NORMALLY OPEN, 1FA, SWITCH/MAGNET SET:							
N1178CT3750B/STHS N1178CT3750G/STHS N1178CT3750T/STHS N1178CT3750W/STHS	BROWN GREY TAN WHITE	0.1875 to 0.5000	300 VDC	0.25 Amps	10vA	0.25 Amps	150 mOhms initial


WIRING SCHEMATIC



DIMENSIONS - IN [mm]



SWITCH



MAGNET

INSTALLATION INSTRUCTIONS

- Mark location for the switch on the door frame and mark the location for the magnet on the door.
- Make sure switch and magnet hole locations are aligned.
- Drill holes for the switch and magnet using a 3/4" Hole Saw for steel doors or a Forstner bit for wood doors.
- Press the magnet into the hole in the door until seated firmly against the head. Silicone may be used to secure the magnet in wood doors.
- Connect the switch terminals to the alarm circuit conductors. Insert wire leads into hole followed by the switch and press the switch into the hole until the head is flush with the door frame.
- Test switch for correct operation and make sure gap performance is acceptable.

PART NUMBERING SYSTEM

